

LOAD 2_46 Setup List								
Setup Name	Availability				Output patch			
	NX241 or NX242	NX241+ Nxtension CAI	NX242 + NXtensionCAI or ES4	NXAMP	CH1	CH2	CH3	CH4
ALPHATD B1+M3 Wideband-No Sub	X	X	X	X	xxxxxxx	ALPHA B115 Wide	ALPHA MF	ALPHA HF
ALPHATD S2+B1+M3 S2-80Hz	X	X	X	X	ALPHA S2 80	ALPHA B115 Xov	ALPHA MF	ALPHA HF
ALPHATD S2+B1+M3 S2-63Hz	X	X	X	X	ALPHA S2 63	ALPHA B115 Xov	ALPHA MF	ALPHA HF
4 S2 cabinets S2-80Hz	X	X	X	X	ALPHA S2 80	ALPHA S2 80	ALPHA S2 80	ALPHA S2 80
4 S2 cabinets S2-63Hz	X	X	X	X	ALPHA S2 63	ALPHA S2 63	ALPHA S2 63	ALPHA S2 63
ALPHAe Stereo AEM + B1-18	X	X	X	X	ALPHA B118 Wide	ALPHA B118 Wide	ALPHA E PASSIVE Xov	ALPHA E PASSIVE Xov
ALPHAe Stereo X AEM + B1-18xover	X	X	X	X	ALPHA B118 Xov	ALPHA B118 Xov	ALPHA E PASSIVE Xov	ALPHA E PASSIVE Xov
ALPHAe Mono AEM B1-18 S2-80	X	X	X	X	ALPHA S2 80	ALPHA B118 Xov	ALPHA E PASSIVE Xov	xxxxxxx
ALPHAe Mono AEM B1-18 S2-63	X	X	X	X	ALPHA S2 63	ALPHA B118 Xov	ALPHA E PASSIVE Xov	xxxxxxx
ALPHAe ACTIVE 3W B1-18 MF HF	X	X	X	X	xxxxxxx	ALPHA B118 Wide	ALPHA E MF	ALPHA E HF
ALPHAe ACTIVE 4W S2 B1-18 MF HF	X	X	X	X	ALPHA S2 63	ALPHA B118 Xov	ALPHA E MF	ALPHA E HF
PS15 StereoXover + S2 Stereo		X	X	X	ALPHA S2 XOV PS15	ALPHA S2 XOV PS15	PS15 Xov S2	PS15 Xov S2
PS15 StereoXover + S2 Mono	X				xxxxxxx	ALPHA S2 XOV PS15	PS15 Xov S2	PS15 Xov S2
PS15 Stereo Wide RS15 Omni 80Hz			X	X	RS15 Omni 80Hz	RS15 Omni 80Hz	PS15 Wide RS15	PS15 Wide RS15
PS15 Stereo Wide + LS1200 Stereo		X	X	X	LS1200	LS1200	PS15 Wide	PS15 Wide
PS15 Stereo Wide + LS1200 mono	X				xxxxxxx	LS1200	PS15 Wide	PS15 Wide
PS15 StereoXover + LS1200 Stereo		X	X	X	LS1200	LS1200	PS15 Xov	PS15 Xov
PS15 StereoXover + LS1200 Mono	X				xxxxxxx	LS1200	PS15 Xov	PS15 Xov
2 PS15 ch 3 & 4 2 PS10 ch 1 & 2		X	X	X	PS10 Wide	PS10 Wide	PS15 Wide	PS15 Wide
2 PS15 ch 3 & 4 2 PS8 ch 1 & 2		X	X	X	PS8 Wide	PS8 Wide	PS15 Wide	PS15 Wide
4 PS15 cabinets Wideband		X	X	X	PS15 Wide	PS15 Wide	PS15 Wide	PS15 Wide
PS15 StereoXover RS15 Omni 80Hz			X	X	RS15 Omni 80Hz	RS15 Omni 80Hz	PS15 Xov RS15	PS15 Xov RS15
4 x LS1200 cabinets	X	X	X	X	LS1200	LS1200	LS1200	LS1200
PS15 Active Wide LF(1-2) HF(3-4)	X	X	X	X	PS15 LF Wide	PS15 LF Wide	PS15 HF for WB	PS15 HF for WB
PS15 ActiveXover LF(1-2) HF(3-4)	X	X	X	X	PS15 LF Xov	PS15 LF Xov	PS15 HF for XOV	PS15 HF for XOV
PS15 StereoXover RS15 Cardio 80Hz			X	X	RS15 CARDIO Back 80Hz	RS15 CARDIO front 80Hz	PS15 Xov RS15	PS15 Xov RS15
PS15 Active Mono S2 + LF + HF	X	X	X	X	xxxxxxx	ALPHA S2 XOV PS15	PS15 LF Xov	PS15 HF for XOV
PS15 Active Mono LS1200 + LF + HF	X	X	X	X	xxxxxxx	LS1200	PS15 LF Xov	PS15 HF for XOV
PS15 Xover (2-4) + S2 Stereo(1-3)			X	X	ALPHA S2 XOV PS15	PS15 Xov S2	ALPHA S2 XOV PS15	PS15 Xov S2
PS15 Wide (2-4) + LS1200 St(1-3)			X	X	LS1200	PS15 Wide	LS1200	PS15 Wide
PS15 Xover (2-4) + LS1200 St(1-3)			X	X	LS1200	PS15 Xov	LS1200	PS15 Xov
PS10 Stereo Wide No Sub	X				xxxxxxx	xxxxxxx	PS10 Wide	PS10 Wide
PS10 StereoXover + LS500 Stereo		X	X	X	LS500	LS500	PS10 Xov	PS10 Xov
PS10 StereoXover + LS500 Mono	X				xxxxxxx	LS500	PS10 Xov	PS10 Xov
2 PS10 ch 3 & 4 2 PS8 ch 1 & 2		X	X	X	PS8 Wide	PS8 Wide	PS10 Wide	PS10 Wide
4 PS10 cabinets Wideband		X	X	X	PS10 Wide	PS10 Wide	PS10 Wide	PS10 Wide
PS10 Stereo Wide RS15 Omni 80Hz			X	X	RS15 Omni 80Hz	RS15 Omni 80Hz	PS10 Wide RS15	PS10 Wide RS15
PS10 Stereo Wide RS15 Cardio 80Hz			X	X	RS15 CARDIO Back 80Hz	RS15 CARDIO front 80Hz	PS10 Wide RS15	PS10 Wide RS15
PS10 StereoXover RS15 Omni 80Hz			X	X	RS15 Omni 80Hz	RS15 Omni 80Hz	PS10 Xov RS15	PS10 Xov RS15
PS10 StereoXover RS15 Cardio 80Hz			X	X	RS15 CARDIO Back 80Hz	RS15 CARDIO front 80Hz	PS10 Xov RS15	PS10 Xov RS15
4 x LS500 cabinets	X	X	X	X	LS500	LS500	LS500	LS500
PS10 Xover (2-4) + LS500 St (1-3)			X	X	LS500	PS10 Xov	LS500	PS10 Xov
PS8 Stereo Wide No Sub	X				xxxxxxx	xxxxxxx	PS8 Wide	PS8 Wide
PS8 Stereo Xover + LS400 Stereo		X	X	X	LS400	LS400	PS8 Xov	PS8 Xov
PS8 Stereo Xover + LS400 Mono	X				xxxxxxx	LS400	PS8 Xov	PS8 Xov
PS8 Stereo Wide RS15 Omni 80Hz			X	X	RS15 Omni 80Hz	RS15 Omni 80Hz	PS8 Wide	PS8 Wide
PS8 Stereo Xover RS15 Omni 80Hz			X	X	RS15 Omni 80Hz	RS15 Omni 80Hz	PS8 Xov RS15	PS8 Xov RS15
PS8 Stereo Wide RS15 Cardio 80Hz			X	X	RS15 CARDIO Back 80Hz	RS15 CARDIO front 80Hz	PS8 Wide	PS8 Wide
PS8 Stereo Xover RS15 Cardio 80Hz			X	X	RS15 CARDIO Back 80Hz	RS15 CARDIO front 80Hz	PS8 Xov RS15	PS8 Xov RS15
4 PS8 cabinets Wideband		X	X	X	PS8 Wide	PS8 Wide	PS8 Wide	PS8 Wide
4 x LS400 cabinets	X	X	X	X	LS400	LS400	LS400	LS400
PS8 Xover (2-4) + LS400 St (1-3)			X	X	LS400	PS8 Xov	LS400	PS8 Xov
S805 Mono Wide +CD12 130Hz Mono	X				CD12 Back 130	CD12 Front 130	GEO S805 Wide	xxxxxxx
S805 Mono Wide +CD12 90Hz Mono	X				CD12 Back 90	CD12 Front 90	GEO S805 Wide	xxxxxxx
S805 Mono Xover +CD12 130Hz Mono	X				CD12 Back 130	CD12 Front 130	GEO S805 Xov	xxxxxxx
S805 Mono Xover +CD12 90Hz Mono	X				CD12 Back 90	CD12 Front 90	GEO S805 Xov	xxxxxxx
S805 Stereo Wide No Sub	X				xxxxxxx	xxxxxxx	GEO S805 Wide	GEO S805 Wide
S805 Stereo Wide +CD12 130Hz Mono		X	X	X	CD12 Back 130	CD12 Front 130	GEO S805 Wide	GEO S805 Wide

LOAD 2_46 Setup List								
Setup Name	Availability			NXAMP	Output patch			
	NX241 or NX242	NX241+ Nxtension CAI	NX242 + NXtensionCAI or ES4		CH1	CH2	CH3	CH4
S805 Stereo Wide +CD12 90Hz Mono		X	X	X	CD12 Back 90	CD12 Front 90	GEO S805 Wide	GEO S805 Wide
S805 StereoXover +CD12 130Hz Mono		X	X	X	CD12 Back 130	CD12 Front 130	GEO S805 Xov	GEO S805 Xov
S805 StereoXover +CD12 90Hz Mono		X	X	X	CD12 Back 90	CD12 Front 90	GEO S805 Xov	GEO S805 Xov
S830 Mono Xover +CD12 130Hz Mono	X				CD12 Back 130	CD12 Front 130	GEO S830 Xov	xxxxxxx
S830 Mono Xover +CD12 90Hz Mono	X				CD12 Back 90	CD12 Front 90	GEO S830 Xov	xxxxxxx
S830 Stereo Wide No Sub	X				xxxxxxx	xxxxxxx	GEO S830 Wide	GEO S830 Wide
S830 Stereo Wide +CD12 130Hz Mono		X	X	X	CD12 Back 130	CD12 Front 130	GEO S830 Wide	GEO S830 Wide
S830 Stereo Wide +CD12 90Hz Mono		X	X	X	CD12 Back 90	CD12 Front 90	GEO S830 Wide	GEO S830 Wide
S830 StereoXover +CD12 130Hz Mono		X	X	X	CD12 Back 130	CD12 Front 130	GEO S830 Xov	GEO S830 Xov
S830 StereoXover +CD12 90Hz Mono		X	X	X	CD12 Back 90	CD12 Front 90	GEO S830 Xov	GEO S830 Xov
4 S805 cabinets Wideband		X	X	X	GEO S805 Wide	GEO S805 Wide	GEO S805 Wide	GEO S805 Wide
4 S830 cabinets Wideband		X	X	X	GEO S830 Wide	GEO S830 Wide	GEO S830 Wide	GEO S830 Wide
S805 StereoXover + S2 80Hz Stereo	X				xxxxxxx	ALPHA S2 XOV GEO	GEO S805 Xov	GEO S805 Xov
S805 StereoXover + S2 80Hz Stereo		X	X	X	ALPHA S2 XOV GEO	ALPHA S2 XOV GEO	GEO S805 Xov	GEO S805 Xov
S830 Stereo Wide + S2 80Hz Stereo		X	X	X	ALPHA S2 XOV GEO	ALPHA S2 XOV GEO	GEO S830 Wide	GEO S830 Wide
S830 StereoXover +S2 130Hz Mono	X				xxxxxxx	ALPHA S2 XOV GEO	GEO S830 Xov	GEO S830 Xov
S830 StereoXover + S2 80Hz Stereo		X	X	X	ALPHA S2 XOV GEO	ALPHA S2 XOV GEO	GEO S830 Xov	GEO S830 Xov
S805 Mono Xover +CD18 100Hz Mono	X				CD18 back 100	CD18 front 100	GEO S805 Xov	xxxxxxx
S805 StereoXover +CD18 85Hz Mono		X	X	X	CD18 back 85	CD18 front 85	GEO S805 Xov	GEO S805 Xov
S830 Mono Xover +CD18 100Hz Mono	X				CD18 back 100	CD18 front 100	GEO S830 Xov	xxxxxxx
S830 Stereo Wide +CD18 85Hz Mono		X	X	X	CD18 back 85	CD18 front 85	GEO S830 Wide	GEO S830 Wide
S830 StereoXover +CD18 85Hz Mono		X	X	X	CD18 back 85	CD18 front 85	GEO S830 Xov	GEO S830 Xov
S805 Stereo Wide RS15 Omni 80Hz			X	X	RS15 Omni 80Hz	RS15 Omni 80Hz	GEO S805 Wide	GEO S805 Wide
S805 StereoXover RS15 Omni 80Hz			X	X	RS15 Omni 80Hz	RS15 Omni 80Hz	GEO S805 Xov	GEO S805 Xov
S830 Stereo Wide RS15 Omni 80Hz			X	X	RS15 Omni 80Hz	RS15 Omni 80Hz	GEO S830 Wide	GEO S830 Wide
S830 StereoXover RS15 Omni 80Hz			X	X	RS15 Omni 80Hz	RS15 Omni 80Hz	GEO S830 Xov	GEO S830 Xov
S805 StereoXover RS15 Cardio 80Hz			X	X	RS15 CARDIO Back 80Hz	RS15 CARDIO front 80Hz	GEO S805 Xov	GEO S805 Xov
S830 StereoXover RS15 Cardio 80Hz			X	X	RS15 CARDIO Back 80Hz	RS15 CARDIO front 80Hz	GEO S830 Xov	GEO S830 Xov
S805 StereoXover GeoSub 35-80Hz			X	X	GEO SUB BACK 35-80Hz	GEO SUB FRONT 35-80Hz	GEO S805 Xov	GEO S805 Xov
S805 StereoXover GeoSub 35-200Hz			X	X	GEO SUB BACK 35-200Hz	GEO SUB FRONT 35-200Hz	GEO S805 Xov	GEO S805 Xov
S830 StereoXover GeoSub 35-80Hz			X	X	GEO SUB BACK 35-80Hz	GEO SUB FRONT 35-80Hz	GEO S830 Xov	GEO S830 Xov
S830 StereoXover GeoSub 35-200Hz			X	X	GEO SUB BACK 35-200Hz	GEO SUB FRONT 35-200Hz	GEO S830 Xov	GEO S830 Xov
GeoT 4805-2815 Crossover 140Hz	X	X	X		GEO T4805 BACK 140	GEO T4805 FRONT 140	GEO T4805 HF 75	xxxxxxx
GeoT 4805-2815 Crossover 100Hz	X	X	X		GEO T4805 BACK 100	GEO T4805 FRONT 100	GEO T4805 HF NXSTR	xxxxxxx
GeoT 4805-2815 Crossover 75Hz	X	X	X		GEO T4805 BACK 75	GEO T4805 FRONT 75	GEO T4805 HF 75	xxxxxxx
GeoT NXS Crossover 90Hz			X		GEO T4805 BACK NXSTR	GEO T4805 FRONT NXSTR	GEO T4805 HF 100	xxxxxxx
GeoT Xover 75Hz Back(1) Front(3)				X	GEO T4805 BACK 75	xxxxxxx	GEO T4805 FRONT 75	xxxxxxx
GeoT Xover 100Hz Back(1) Front(3)				X	GEO T4805 BACK 100	xxxxxxx	GEO T4805 FRONT 100	xxxxxxx
GeoT Xover 140Hz Back(1) Front(3)				X	GEO T4805 BACK 140	xxxxxxx	GEO T4805 FRONT 140	xxxxxxx
GeoT NXSTR 90Hz Back(1) Front(3)				X	GEO T4805 BACK NXSTR	xxxxxxx	GEO T4805 FRONT NXSTR	xxxxxxx
GeoT Xover 75Hz HP (1-2-3-4)				X	GEO T4805 HF 75	GEO T4805 HF 75	GEO T4805 HF 75	GEO T4805 HF 75
GeoT Xover 100Hz HP (1-2-3-4)				X	GEO T4805 HF NXSTR	GEO T4805 HF NXSTR	GEO T4805 HF NXSTR	GEO T4805 HF NXSTR
GeoT Xover 140Hz HP (1-2-3-4)				X	GEO T4805 HF 75	GEO T4805 HF 75	GEO T4805 HF 75	GEO T4805 HF 75
GeoT NXSTR 90Hz HP (1-2-3-4)				X	GEO T4805 HF 100	GEO T4805 HF 100	GEO T4805 HF 100	GEO T4805 HF 100
CD18 Cardio Crossover 140Hz	X	X	X	X	CD18 back 140	CD18 front 140	CD18 back 140	CD18 front 140
CD18 Cardio Crossover 100Hz	X	X	X	X	CD18 back 100	CD18 front 100	CD18 back 100	CD18 front 100
CD18 Cardio Crossover 85Hz			X	X	CD18 back 85	CD18 front 85	CD18 back 85	CD18 front 85
CD18 Cardio Crossover 75Hz	X	X	X	X	CD18 back 75	CD18 front 75	CD18 back 75	CD18 front 75
CD12 stereo Crossover 130 Hz	X	X	X	X	CD12 Back 130	CD12 Front 130	CD12 Back 130	CD12 Front 130
CD12 stereo Crossover 90 Hz	X	X	X	X	CD12 Back 90	CD12 Front 90	CD12 Back 90	CD12 Front 90
GeoSUB 75-200Hz +CD18 85Hz Mono			X	X	CD18 back 85	CD18 front 85	GEO SUB BACK 75-200Hz	GEO SUB FRONT 75-200Hz
CD12-130Hz(3-4) +CD18-85Hz (1-2)			X	X	CD18 back 85	CD18 front 85	CD12 Back 130	CD12 Front 130
GeoD Stereo Wideband			X	X	GEOD 10 BACK Wide	GEOD 10 FRONT Wide	GEOD 10 BACK Wide	GEOD 10 FRONT Wide
GeoD Stereo Crossover			X	X	GEOD 10 BACK Xov	GEOD 10 FRONT Xov	GEOD 10 BACK Xov	GEOD 10 FRONT Xov
GeoD Wide (3-4) +CD18 85Hz Mono			X	X	CD18 back 85	CD18 front 85	GEOD 10 BACK Wide	GEOD 10 FRONT Wide
GeoD Xover (3-4) +CD18 85Hz Mono			X	X	CD18 back 85	CD18 front 85	GEOD 10 BACK Xov	GEOD 10 FRONT Xov
GeoD Wide (3-4) GeoSub 35-80Hz			X	X	GEO SUB BACK 35-80Hz	GEO SUB FRONT 35-80Hz	GEOD 10 BACK Wide	GEOD 10 FRONT Wide
GeoD Xover (3-4) GeoSub 35-80Hz			X	X	GEO SUB BACK 35-80Hz	GEO SUB FRONT 35-80Hz	GEOD 10 BACK Xov	GEOD 10 FRONT Xov

LOAD 2_46 Setup List								
Setup Name	Availability			NXAMP	Output patch			
	NX241 or NX242	NX241+ Nxtension CAI	NX242 + NXtensionCAI or ES4		CH1	CH2	CH3	CH4
GeoD Xover (3-4)			X	X	GEO SUB BACK 35-200Hz	GEO SUB FRONT 35-200Hz	GEO D 10 BACK Xov	GEO D 10 FRONT Xov
GeoSub 35-200Hz			X	X	GEO SUB BACK 35-200Hz	GEO SUB FRONT 35-200Hz	GEO SUB BACK 35-200Hz	GEO SUB FRONT 35-200Hz
GeoSub 35-80Hz			X	X	GEO SUB BACK 35-80Hz	GEO SUB FRONT 35-80Hz	GEO SUB BACK 35-80Hz	GEO SUB FRONT 35-80Hz
GeoSub 75-200Hz			X	X	GEO SUB BACK 75-200Hz	GEO SUB FRONT 75-200Hz	GEO SUB BACK 75-200Hz	GEO SUB FRONT 75-200Hz
GeoD 3way Active Wideband			X	X	GEO D 10 BACK Wide	GEO D 10 FRONT ACT. Wide	GEO D 10 HF ACT.	xxxxxxx
GeoD 3way Active Crossover			X	X	GEO D 10 BACK Xov	GEO D 10 FRONT ACT. Xov	GEO D 10 HF ACT.	xxxxxxx
S1210 NXS Wide			X	X	GEO SUB BACK 35-80Hz	GEO SUB FRONT 35-80Hz	GEO S1210 Wide	GEO S1210 Wide
S1210 NXS Wide			X	X	GEO SUB BACK 35-200Hz	GEO SUB FRONT 35-200Hz	GEO S1210 Wide	GEO S1210 Wide
S1210 NXS Xover			X	X	GEO SUB BACK 35-80Hz	GEO SUB FRONT 35-80Hz	GEO S1210 Xov	GEO S1210 Xov
S1210 NXS Xover			X	X	GEO SUB BACK 35-200Hz	GEO SUB FRONT 35-200Hz	GEO S1210 Xov	GEO S1210 Xov
S1210 NXS Wide + S2 Stereo			X	X	ALPHA S2 XOV GEO	ALPHA S2 XOV GEO	GEO S1210 Wide	GEO S1210 Wide
S1210 NXS Xover + S2 Stereo			X	X	ALPHA S2 XOV GEO	ALPHA S2 XOV GEO	GEO S1210 Xov	GEO S1210 Xov
S1210 NXS Wide +CD18 85Hz Mono			X	X	CD18 back 85	CD18 front 85	GEO S1210 Wide	GEO S1210 Wide
S1210 NXS Xover +CD18 85Hz Mono			X	X	CD18 back 85	CD18 front 85	GEO S1210 Xov	GEO S1210 Xov
S1210 NXS Wide RS15 Omni 80Hz			X	X	RS15 Omni 80Hz	RS15 Omni 80Hz	GEO S1210 Wide	GEO S1210 Wide
S1210 NXS Xover RS15 Omni 80Hz			X	X	RS15 Omni 80Hz	RS15 Omni 80Hz	GEO S1210 Xov	GEO S1210 Xov
S1210 NXS Xover RS15 Cardio 80Hz			X	X	RS15 CARDIO Back 80Hz	RS15 CARDIO front 80Hz	GEO S1210 Xov	GEO S1210 Xov
S1210 NXS Wide RS15 Cardio 80Hz			X	X	RS15 CARDIO Back 80Hz	RS15 CARDIO front 80Hz	GEO S1210 Wide	GEO S1210 Wide
4 S1210 cabinets Wideband NXS			X	X	GEO S1210 Wide	GEO S1210 Wide	GEO S1210 Wide	GEO S1210 Wide
S1210 Active Xov LF(1-2) HF(3-4)			X	X	GEO S1210 LF LF Xov	GEO S1210 LF LF Xov	GEO S1210 HF ACT.	GEO S1210 HF ACT.
S1210 ActiveWide LF(1-2) HF(3-4)			X	X	GEO S1210 LF Wide	GEO S1210 LF Wide	GEO S1210 HF ACT.	GEO S1210 HF ACT.
S1210 Active Xov +CD18 85Hz Mono			X	X	CD18 back 85	CD18 front 85	GEO S1210 LF LF Xov	GEO S1210 HF ACT.
S1210 Active Xov GeoSub 35-80Hz			X	X	GEO SUB BACK 35-80Hz	GEO SUB FRONT 35-80Hz	GEO S1210 LF LF Xov	GEO S1210 HF ACT.
S1210 Active Xov GeoSub 35-200Hz			X	X	GEO SUB BACK 35-200Hz	GEO SUB FRONT 35-200Hz	GEO S1210 LF LF Xov	GEO S1210 HF ACT.
S1210 Active Xov RS15 Cardio 80Hz			X	X	RS15 CARDIO Back 80Hz	RS15 CARDIO front 80Hz	GEO S1210 LF LF Xov	GEO S1210 HF ACT.
S1210 ActiveWide RS15 Cardio 80Hz			X	X	RS15 CARDIO Back 80Hz	RS15 CARDIO front 80Hz	GEO S1210 LF Wide	GEO S1210 HF ACT.
S1210 Active Xov + S2 Stereo			X	X	ALPHA S2 XOV GEO	ALPHA S2 XOV GEO	GEO S1210 LF LF Xov	GEO S1210 HF ACT.
S1210 Active Xov RS15 Omni 80Hz			X	X	RS15 Omni 80Hz	RS15 Omni 80Hz	GEO S1210 LF LF Xov	GEO S1210 HF ACT.
S1230 NXS Wide GeoSub 35-80Hz			X	X	GEO SUB BACK 35-80Hz	GEO SUB FRONT 35-80Hz	GEO S1230 Wide	GEO S1230 Wide
S1230 NXS Wide GeoSub 35-200Hz			X	X	GEO SUB BACK 35-200Hz	GEO SUB FRONT 35-200Hz	GEO S1230 Wide	GEO S1230 Wide
S1230 NXS Xover GeoSub 35-80Hz			X	X	GEO SUB BACK 35-80Hz	GEO SUB FRONT 35-80Hz	GEO S1230 Xov	GEO S1230 Xov
S1230 NXS Xover GeoSub 35-200Hz			X	X	GEO SUB BACK 35-200Hz	GEO SUB FRONT 35-200Hz	GEO S1230 Xov	GEO S1230 Xov
S1230 NXS Wide + S2 stereo			X	X	ALPHA S2 XOV GEO	ALPHA S2 XOV GEO	GEO S1230 Wide	GEO S1230 Wide
S1230 NXS Xover + S2 Stereo			X	X	ALPHA S2 XOV GEO	ALPHA S2 XOV GEO	GEO S1230 Xov	GEO S1230 Xov
S1230 NXS Wide +CD18 85Hz Mono			X	X	CD18 back 85	CD18 front 85	GEO S1230 Wide	GEO S1230 Wide
S1230 NXS Xover +CD18 85Hz Mono			X	X	CD18 back 85	CD18 front 85	GEO S1230 Xov	GEO S1230 Xov
S1230 NXS Wide RS15 Omni 80Hz			X	X	RS15 Omni 80Hz	RS15 Omni 80Hz	GEO S1230 Wide	GEO S1230 Wide
S1230 NXS Xover RS15 Omni 80Hz			X	X	RS15 Omni 80Hz	RS15 Omni 80Hz	GEO S1230 Xov	GEO S1230 Xov
S1230 NXS Xover RS15 Cardio 80Hz			X	X	RS15 CARDIO Back 80Hz	RS15 CARDIO front 80Hz	GEO S1230 Xov	GEO S1230 Xov
S1230 NXS Wide RS15 Cardio 80Hz			X	X	RS15 CARDIO Back 80Hz	RS15 CARDIO front 80Hz	GEO S1230 Wide	GEO S1230 Wide
4 S1230 cabinets Wideband NXS			X	X	GEO S1230 Wide	GEO S1230 Wide	GEO S1230 Wide	GEO S1230 Wide
S1230 Active Xov RS15 Cardio 80Hz			X	X	RS15 CARDIO Back 80Hz	RS15 CARDIO front 80Hz	GEO S1230 LF Xov	GEO S1230 HF ACT.
S1230 ActiveWide RS15 Cardio 80Hz			X	X	RS15 CARDIO Back 80Hz	RS15 CARDIO front 80Hz	GEO S1230 LF Wide	GEO S1230 HF ACT.
S1230 Active Xov LF(1-2) HF(3-4)			X	X	GEO S1230 LF Xov	GEO S1230 LF Xov	GEO S1230 HF ACT.	GEO S1230 HF ACT.
S1230 ActiveWide LF(1-2) HF(3-4)			X	X	GEO S1230 LF Wide	GEO S1230 LF Wide	GEO S1230 HF ACT.	GEO S1230 HF ACT.
S1230 Active Xov +CD18 85Hz Mono			X	X	CD18 back 85	CD18 front 85	GEO S1230 LF Xov	GEO S1230 HF ACT.
S1230 Active Xov GeoSub 35-80Hz			X	X	GEO SUB BACK 35-80Hz	GEO SUB FRONT 35-80Hz	GEO S1230 LF Xov	GEO S1230 HF ACT.
S1230 Active Xov GeoSub 35-200Hz			X	X	GEO SUB BACK 35-200Hz	GEO SUB FRONT 35-200Hz	GEO S1230 LF Xov	GEO S1230 HF ACT.
S1230 Active Xov + S2 Stereo			X	X	ALPHA S2 XOV GEO	ALPHA S2 XOV GEO	GEO S1230 LF Xov	GEO S1230 HF ACT.
S1230 Active Xov RS15 Omni 80Hz			X	X	RS15 Omni 80Hz	RS15 Omni 80Hz	GEO S1230 LF Xov	GEO S1230 HF ACT.
RS15 Omni 80Hz			X	X	RS15 Omni 80Hz	RS15 Omni 80Hz	RS15 Omni 80Hz	RS15 Omni 80Hz
RS15 Cardio 80Hz			X	X	RS15 CARDIO Back 80Hz	RS15 CARDIO front 80Hz	RS15 CARDIO Back 80Hz	RS15 CARDIO front 80Hz